

Clean linen range

Nursing trolleys

Photos are not contractual

The range of nursing trolleys streamlines and facilitates the work of nursing assistants. The **ergonomic** design and **modular** concept of storage compartments make it easy to adapt the trolley to each ward's needs.

Computerized management is possible by adding a secured computer holder to the trolley.



Hygienic



Ergonomic

Advantages

- ▶ Open or closed model with sliding doors
- ▶ 2 models: 15 to 20 patients and 20 to 30 patients
- ▶ Pushing handle integrated into the structure
- ▶ Adjustable-height middle tray with removable dividers
- ▶ Several storage areas
- ▶ Materials resistant to corrosion and disinfecting products

Clean linen range

Nursing trolleys

Open nursing trolley

Technical features

- ▶ Ø 30 mm tubular structure made of machine-welded steel epoxy coating
- ▶ Steel sheet 15/10 upper tray with epoxy coating
- ▶ 4 Ø 125 mm, swivelling wheels inc. 1 with brake, 1 with directional system
- ▶ Polyamide wheels with non marking rubber
- ▶ Available colours:

Pop blue (BP) Apple green (VP) Orange (OR) Raspberry (FR) Blueberry (MY)



Open « standard » trolley

Standard equipments

- ▶ 1 600 x 400 sliding drawer under upper shelf
- ▶ 1 small built-in tray on upper shelf
- ▶ 2 lateral big wire baskets
- ▶ 1 middle removable adjustable shelf
- ▶ Removable dividers on the middle shelf (3 for the « Standard », 2 for the « Mini » model)

NURSING TROLLEYS 15 TO 20 PATIENTS

	Dimensions (in mm)	Reference
« Mini » open trolley	L. 1085 x D. 630 x H. 994	8P200XX
« Mini » open trolley with motorized wheel - pop blue	L. 1085 x D. 630 x H. 994	8P200BP_MOTOR

NURSING TROLLEYS 20 TO 30 PATIENTS

	Dimensions (in mm)	Reference
Open « standard » trolley	L. 1285 x D. 630 x H. 994	8P100XX
Open « standard » trolley with motorized wheel - pop blue	L. 1285 x D. 630 x H. 994	8P100BP_MOTOR

Closed nursing trolley

Technical features

- ▶ Ø 30 mm tubular structure made of machine-welded steel epoxy coating
- ▶ Steel sheet 15/10 upper tray with epoxy coating
- ▶ Sliding doors with key lock
- ▶ 4 Ø 125 mm, swivelling wheels inc. 1 with brake, 1 with directional system
- ▶ Polyamide wheels with non marking rubber
- ▶ Available colours:

Pop blue (BP) Apple green (VP) Orange (OR) Raspberry (FR) Blueberry (MY)



« Mini » trolley with doors

Clean linen range

Nursing trolleys

Standard equipments

- ▶ 1 built-in tray on upper shelf
- ▶ 2 lateral big wire baskets
- ▶ 1 middle removable adjustable shelf
- ▶ Removable dividers on the middle shelf (3 for the « Standard », 2 for the « Mini » model)

Title	Dimensions (in mm)	Reference
« Mini » trolley with doors	L. 1085 x D. 630 x H. 994	8P200XX_P
« Standard » trolley with doors	L. 1285 x D. 630 x H. 994	8P100XX_P

Optional accessories

Title	Picture	Reference	Title	Picture	Reference
Removable 3-compartment upper divider		8P004	Vertical support for allocation sheets		AN09403
Small wire basket Large wire basket		28062N.GR 28061N.GR	Side holder for laundry hamper		22001_S
Paper roll holder		28059N.GR	Side holder for laundry hamper with hygienic panel		AN01070
Holder for glove box		28001N.GR			

Motorisation

All our nursing trolleys can be equipped with the motorized wheel EasyMoove. This innovation enables to reduce physical efforts of the users. A simple act with the finger on the handle allows the system to operate. Staff's work is therefore with utmost convenience.

Description	Reference
EasyMoove motorized wheel for « Mini » nursing trolley (to order at the same time than trolley)	9R002_L02
EasyMoove motorized wheel for « Mini » nursing trolley (for after sales assembling as spare part, price without assembling)	9R002_L02_AV
EasyMoove motorized wheel for « Standard » nursing trolley (to order at the same time than trolley)	9R002_L03
EasyMoove motorized wheel for « Standard » nursing trolley (for after sales assembling as spare part, price without assembling)	9R002_L03_AV

